

TESTER DE PILAS



Baterý tester // Testeur de batterie // Testador de batería //
Tester di pile // Batterie-tester

Para // For // Pour // Para // A // Für

**Pilas
1.5V a 9V**

Embalaje // Packing // Emballage // Embala-
gem // Imballaggio // Verpackung


100

Para pilas de 1.5V: AAA / HP16 / MN2400 / R03 / AA / HP7 /
MN1500 / UM3 / C / HP / MN1400 / SP11 LR14 / UM2 / D /
HP2 / MN1300 / SP2 / R20


Para pilas de 9V: PP3 / MN1604 / 6F22 / 006P

Fácil lectura // Easy reading // Lecture facile // Leitura facil //
Facile lettura // Leichtes Lesen

PILAS DE 1.5V



PILAS DE 9V



PILAS BOTÓN

