

MANDO UNIVERSAL

TV PHILIPS



Remote control // Télécommande // Controle remoto // Controllo remoto // Fernbedienung

Pilas no incluídas // Batteries not included // Piles non incluses // Batterie non incluse // Batterien nicht im Lieferumfang enthalten

2 x AAA

Distancia de funcionamiento // Operating distance // Distance de fonctionnement // Distância de operação // Distanza operativa // Betriebsabstand **> 8m**

Voltaje // Voltage // Tension // Voltagem // Tensione // SpannungKabel **DC 3V**

Embalaje // Packing // Emballage // Embalagem // Imballaggio // Verpackung **100**

MODELOS COMPATIBLES

2422 5490 01833	RC19335003/01	RC7533
2422 5490 01834	RC19335029-01	RC7535
2422 5490 01911	RC2001	RC7599
PH28 LCD TV	RC2006	RC8922
RC1205B/30063555	RC2030	RC8925
RC1683701	RC2031	RC8927
RC1683801/01	RC2048	RC5536
RC19335023-01H	RC2080	RC520
RC2023601	RC25109/01	RC7502
RC2033601/01	RC2512	RC0301/01-47
RC2034301-01	RC2521	RC400
RC2034302-01	RC2525	PHILIPS
RC20340305/01B	RC2525/01	RC115300101
RC2034312/01	RC2529/01	RC19335004/01
RC2143606/01	RC2533	RC1153053-00
RC2683204/01	RC2541	RC7807
RC4344-01H	RC2543	SMART TXT
RC4422/01	RC2563	RC2882-01
RCA10U81FX	RC2582/01	RC-19335014/01
TELEVISIÓN	RC7808	RC2835/01
RC0764/01	RC7812	RC19335019/01
RC7802-S	RC7940	RC19335020/01
RC7812-S	RC7952	RC19335021/01
RC7847	RC7953	RC19335009/01
SAA3010	RC7954	RC19042003/01
RC6805	RC7959	RC19042008/01
RC7802	RC7962	RC19042009/01
RC7805	RC7974	RC19042011/01
RC7806	RC283501	RC19002_B
RC0770	RC283502	RC19039001-01
RC19036002	RC283501	RC0717-642
RC1904	RC2529	RC2023617/01
RC1904/001	RC2575	RC1683702/01
RC19042004	RC8205	RC1152605/01
RC19042011	RC19335003/120	RC1112516/00
RC19042013	RC19039001	0764/01
RC19042018/01	RC19042001	HE888
RC19137008/01	RC7502	PHILIPS PIP
RC19335001	RC7507	Más...

